


















Assembly Egaliner Epic

Part list

| EL-EW-120 | EL-EW-210 | | |
|-----------|-----------|----------------|--|
| 2x | 2x | EL-0000-001 |  |
| 1x | 1x | EL-0000-003 |  |
| 1x | 1x | EL-0000-020 |  |
| 2x | 2x | EL-0000-024 |  |
| 2x | 2x | EL-0000-026 |  |
| 1x | 1x | EL-0000-027 |  |
| 2x | 2x | EL-0000-031 |  |
| 4x | 6x | EL-0000-033 |  |
| 2x | 4x | EL-EW-0000-001 |  |
| 2x | 4x | EL-EW-0000-002 |  |
| 2x | 2x | EL-EW-0000-003 |  |
| 2x | 2x | EL-EW-0000-004 |  |





Wheel

Wheel

